


QUICK INSTALLATION GUIDE

IMPORTANT NOTICE!

This device employs high-precision Ultrasonic Measurement Technology to achieve optimal monitoring of the water usage. To ensure the device functions as intended, it is recommended that it be installed in the manner described, which effectively mitigates the impact of air bubbles in the water pipe on the device.


> WHERE TO INSTALL IT AT HOME




> WATER PIPE CONNECTION

If the diameter pipe is 3/4"

IMPORTANT NOTICE: DO NOT USE TAPE WHEN USING 3/4" ADAPTERS!



If the diameter pipe is 1"





QUICK INSTALLATION GUIDE

› INSTALLATION METHOD



Horizontal installation

Method 1:



Vertical Installation

Method 2:



- *If conditions permit, allow A (inlet pipe) >5 inches , B (outlet pipe) >3 inches
- *Ensure device screen should face upwards. (horizontal installation)
- *Ensure water flow direction is upwards. (vertical installation)

› SWITCH WATER INLET/OUTLET DIRECTION

If you have a special need to switch the direction of the inlet and outlet of the device, refer to the instructions in the manual “**OPERATION AND SETTING**” ➡